


INSTALLATION INSTRUCTIONS

Y-10T

VIRAGO

Please Read All Steps Prior to Installing Oil Cooler.

1. Remove oil filter from engine, remove "O" rings from oil filter cover.
2. Modify the oil filter cover per Figs. 2 and 3, blowout all chips from oil filter cover. Install "O" rings on cover.
3. Install Derale flow adapter and Derale "O" ring in cover per Fig. 1. Install oil filter cover on engine. Be sure you install the oil filter.
4. Install pipe thread sealant on the two right angle fittings and install the fittings in cover per Fig. 1.



5. Install pipe thread sealant on the two straight barb fittings, and install fittings in the right angle fittings per Fig. 1.
6. Assemble the oil cooler per Fig. 1.
NOTE: When installing the Allen bolt thru the frame hole, place the Allen bolt on the short side of an Allen wrench (Hex Key), put a washer on the bolt, install the bolt.
7. Install the hose bracket and rubber covered hose clamps. Make sure the oil hoses are not touching the engine. Make sure the screws and hose clamps are tight.
8. Bring the oil up to the correct level, start the engine and check for leaks.

Installation Tips:

- (A) Install hose clamp on oil hose prior to installing oil hose.
- (B) Wet the inside of the oil hose with oil prior to installing the hose on the oil cooler and fittings.
- (C) When tapping the center hole in the oil filter cover, do not tap too deep. The depth should be deep enough so you can install the 90° fittings by hand approximately two (2) turns.

**YOU HAVE THE WORLD'S FINEST OIL COOLER
THANK YOU FOR BUYING A DERALE OIL COOLER
"HAPPY BIKING"**



138 West Gardena Boulevard, Gardena, California 90248 / (213) 532-5997, 515-7266